


EXTRATOR (ES4AB-S)



Item	Código	Descrição
1	04046-7	Tampa
2	23119-7	Castanha Gr. p/ Eixo do Motor
3	23118-7	Castanha Pq. p/ Eixo do Motor
4	04406-7	Copo
5	04032-7	Cúpula
6	04072-7	Arruela de Borracha
7	00612-7	Porca Boleada
8	04030-7	Chapéu
9	23399-7	Motor
10	04033-7	Corpo
11	20466-7	Interruptor
12	16693-7	Fundo
13	04044-7	Base
14	03000-7	Batente de Borracha
15	23101-7	Rabicho
16	04405-7	Peneira
17	20458-7	Interruptor Deslizante
18	23109-7	Placa antirrearme
19	09422-7	Prensa Cabo
20	00359-7	Parafuso 3/16"
21	00604-7	Porca 3/16"
22	00643-7	Arruela 3/16"

